




LEVISTICK INFOS

HOW IT WORKS?

The yo-yo loop should be tied to the end of the middle finger of your preferred hand. Don't worry, even if the stick initially feels heavy, you can't accidentally bind your finger. To release the loop from your finger, the string should not be under tension. Make sure you have enough space to play, around 1 meter around you should be enough to be able to show or try all the tricks. The stick has a top and bottom side. If the bottom side is up, the stick will spin by itself. Only when the stick is calm and stabilized can you start playing. (With some practice, you can also start with a swing)."

You don't know how to
make a yo-yo loop?

Here is a picture. →



„DON'T TOUCH THE STICK" IS THE MOST IMPORTANT RULE!

The stick swings smoothly only when the string has enough tension, and it can move freely. This means that as soon as it touches the ground, an object, your arm, clothing, or another person, it loses its momentum and wobbles uncontrollably. Once this happens, you can no longer stabilize it, and you must start over.

HANDLING & STORAGE

Since the stick is completely covered with a hose and the ends are sealed, it is protected against weather and water damage by 99%. You can leave the stick in damp grass and play in the rain without any problems; however, you should dry it thoroughly afterward, as water can penetrate through the small hole where the thread passes.

(Under no circumstances should the stick be taken into water or submerged in water.)

Always store the stick lying down or hanging from the string, as it could deform otherwise.

I hope you have a lot of fun with your new Levistick and can soon impress everyone with your levitation tricks. Create your own stick by simply downloading the provided form, filling it out, and emailing it back to me.

Good Luck and have Fun!